

Zebex 3220

[Configuration Sheet]



| Barcode | Function |
|---|--------------------------|
|  | Enter Configuration Mode |
|  | Add Prefix |
|  | Add Tilde |
|  | Validate Prefix |
|  | Set Prefix |
|  | Add Suffix |
|  | Add Enter |
|  | Validate Suffix |
|  | Set Suffix |
|  | Exit Config Mode |